



MULTI-GEAR TIRE LOCK


Product Features

- Use the combination of gears, which is hard to decipher
- The structure is equipped with over 32 combination ways
- After installation, there will be 2 parts
 - Lock body → Locked on the tires
 - Gear-key → The lock body cannot be unlocked without the gear-key




Installation


Use the gear-key to match the dust cover.




Take out the dust cover.




Roll in the lock body.



Use the gear-key and 21mm socket wrench to tight up the lock body.



Use gear-key to tight up the dust cover.





輪胎鎖


產品特性

- 使用多重排列齒輪機構來使得竊賊無法輕易破解。
- 多重齒輪排列機構共有32種以上排列組合方式。
- 產品由輪胎鎖本體及開鎖工具兩部份組成，當輪胎鎖安裝完成之後，需以此特製開鎖工具進行解鎖，非一般套筒扳手可解鎖，相對增加防盜效果。




安裝流程


1 用特殊開鎖工具嵌合進防塵蓋凹槽防塵蓋。




2 取下防塵蓋。



3 將力巨人輪胎鎖旋入輪胎螺栓。



4 以特殊開鎖工具搭配21mm套筒扳手將輪胎鎖鎖上。



5 使用特殊開鎖工具將防塵蓋鎖入。

